

DESCRIPTION

The dosing group series is the natural complement to the dosing pumps and manual or electric mixers. They can also be combined with containment tank

APPLICATIONS

- ✓ Pools
- ✓ Spa
- ✓ Industry

FEATURES

- ✓ PE high density polyethylene tanks, graduated to allow to view the level of the chemical product within
- ✓ Possibility to accommodate the full range of MICRODOS metering pumps using mounting bracket
- ✓ Screw cap for closing and sealing
- ✓ Containment tanks can be used to avoid leakages
- ✓ PVDF grommets to prevent oxidation or leakage of chemical fumes
- ✓ **FKM/VITON** standard seals also available upon request EPDM/DUTRAL or silicone



DOSING GROUP

Data
Sheet

FEATURES

TAN PP tank with suction filter with lip valve and FKM / VITON seals pre-mounted, to allow the metering pump suction. Complete with PVC 4x6 bleeding tube.

TAN + LEV PP tank with suction filter with lip valve and FKM / VITON seals pre-mounted, to allow the metering pump suction. Complete with PVC 4x6 bleeding tube and level probe to stop the dosing when the tank is empty.

GP PP tank with suction filter with lip valve and FKM / VITON seals pre-mounted, to allow the metering pump suction. Complete with PVC 4x6 bleeding tube. Supplied with MICRODOS pump mounting bracket

GPL PP tank with suction filter with lip valve and FKM / VITON seals pre-mounted, to allow the metering pump suction. Complete with PVC 4x6 bleeding tube and level probe to stop the dosing when the tank is empty. Supplied with MICRODOS pump mounting bracket

GA PP tank with suction filter with lip valve and FKM / VITON seals pre-mounted, to allow the metering pump suction. Complete with PVC 4x6 bleeding tube. Supplied with pre-drilled holes for housing agitator.

GAL PP tank with suction filter with lip valve and FKM / VITON seals pre-mounted, to allow the metering pump suction. Complete with PVC 4x6 bleeding tube. Supplied with pre-drilled holes for housing agitator. Complete with level probe to stop the dosing when the tank is empty.

GPA PP tank with suction filter with lip valve and FKM / VITON seals pre-mounted, to allow the metering pump suction. Complete with PVC 4x6 bleeding tube. Supplied with pre-drilled holes for housing agitator. Supplied with MICRODOS pump mounting bracket.

GPAL PP tank with suction filter with lip valve and FKM / VITON seals pre-mounted, to allow the metering pump suction. Complete with PVC 4x6 bleeding tube. Supplied with pre-drilled holes for housing agitator. Complete with level probe to stop the dosing when the tank is empty and pump mounting bracket.

MODEL	LEVEL PROBE	PUMP BRACKET	MIXER BRACKET	FILTER
TAN	No	No	No	Yes
TAN + LEV	Yes	No	No	Yes
GP	No	Yes	No	Yes
GPL	Yes	Yes	No	Yes
GA	No	No	Yes	Yes
GAL	Yes	No	Yes	Yes
GPA	No	Yes	Yes	Yes
GPAL	Yes	Yes	Yes	Yes